

Step 0:		Windows 7 and later:
Before you start	Disable the "Themes"	' service from Control Panel → Administrative Tools → Services
installed before running this procedure.	AlwaysUp and V	/isualKB must be run as an Administrator
Disable Themes, Run as an Administrator and back up your files.	Always backup your proc	DGN file and the VisualKB folder before this edure and before any upgrade
Step 1: AlwaysUp Installation	/public/en/ins	tallers/AlwaysUp/
Download AlwaysUp from: <u>http://www.virtualmeltshop.com/public/e</u> <u>n/installers/AlwaysUp/</u> AlwaysUp.zip is the file name	[To Parent Directory] 1/19/2017 5:55 PM 1/19/2017 5:55 PM 4 3/5/2013 3:35 PM 9/25/2013 8:58 AM	553501 <u>Alwaysup.install.doc.ver.2.0.docx</u> 400298 <u>AlwaysUp.zip</u> 3889 <u>VisualKB_SanityCheck.zip</u>
Also download: VisualKB_SanityCheck.zip.		
Step 2: Decompress files		
Once downloaded, decompress files AlwaysUp.zip and VisualKB_SanityCheck.zip	You	will need an unzipping utility
	记 Setup - AlwaysUp	+ – 🗆 🗙
Step 2.1: Files included in the zip file Two files will be included: AlwaysUp_8.8.0.43.exe and alwaysup.dat First run AlwaysUp_8.8.0.43.exe, and follow the on-screen instructions up to the last screen of the installer wizard.	AlwaysUp AlwaysUp AlwaysUp Eastly film four Aug 24.7 As A Windows Service!	Welcome to the AlwaysUp Setup Wizard This will install AlwaysUp Version 8.8 on your computer. It is recommended that you close all other applications before continuing. Click Next to continue, or Cancel to exit Setup.
		Next > Cancel



Step 4: Configure AlwaysUp Open AlwaysUp and click on the "Add a new application" button (sprocket with green plus sign)	AlwaysUp - licensed to AMI GE International (OEM) File Yiew Application Tools Help Yiew Application (Ctrl+A) Yie Arguments Add a new application (Ctrl+A) Yipplication & Arguments There are no applications being managed. Select "Add" from the "Application" menu to add one.
Step 4.1: Set the application settings as shown on the images to the right. For the "Application:" field, select the VisualKB.exe file from the installation folder in the computer.	Add Application Image: Second Secon

	General Logon Restart Monitor Email Startup Automate Extras	
	Name: SmartArc	
	Application: C:\Program Files (x86)\AMI GE\Vi:	
Step 4.2: Optional Arguments	Arguments: E:\VisualKB\VKB\TestDGN\AM_LC.dgn	
Type the path (location) of the .dgn file.	Start in directory:	
Please make sure this matches the exact file name and location of the VisualKB tree	Start the application: Automatically, when the computer boots	
file.	Set the priority to: Normal (for regular applications)	
	Reduce the priority to "Normal" when a user logs on to the computer	
	General Logon Restart Monitor Email Startup Automate Extras	
Step 4.3: Win 7 and later	Instead of running the application in the Local System Account (the default for windows services), run the application using this account:	
	User name: SmartArc	
In case your OS is Windows 7 and later, go to the "Logon" tab.	Password:	
Type the username and password of the account that will run VisualKB.	This user will require specific privileges to allow your application to interact with the desktop (to show its windows and tray icons when someone is logged on).	
Standard AMI GE username and password:	Any user in the "Administrators" group should have the necessary privileges.	
Username: SmartArc Password: nexus	When a user logs on, don't show the application's windows and tray icons (if any)	
This may vary in your setup. You may also execute SmartArc with a username with appropriate permissions.		

	Add Application \qquad ? \qquad
	Configure application settings Please provide the settings for your new application. Click on the Save button to add the application.
Step 4.4: Restart settings Go to the "Restart" tab Uncheck "Stop trying after:"	General Logon Restart Monitor Email Startup Automate Extras When the application stops, restart it: Immediately Not immediately, but: On the next hour On the next hour or half-hour Atter: 80 * seconds * At: 10:58:15 AM * This delay applies to the first run as well Suspend the PC while waiting (if no one is logged on) Stop trying after: 5 * attempts in Xtop trying after: 5 * attempts in
	SANITY CHECK
Step 4.5: Enable Sanity Check Go to the "Monitor" tab and check	Whenever it fails a "sanity check"
"Whenever it fails a 'sanity check':"	

	Edit/View Application				
Step 4.6: Configure Sanity Check settings Click on the "" button to open the "Configure Sanity Check" settings.	Edit/View Application Configure application settings Edit/View the settings of this application. Clock on the Save button to commit your changes. Ceneral Logon Restart Monitor Email Startup Automate Extras Monitor the application and stop it Whenever it "hangs" for longer than: Whenever its memory usage exceeds: S12 MB Whenever it fails a "sanity check" (Vione specified Click to conligue) Every: Dey at 12:00:00 a.m. MB It has been idle for at least: 10 minute(s) No one is logged on to the computer (Keep checking/hying for up to: 60 minute(s) Reboot the computer 				
	Note: After it is stopped, the application will be restarted as specified on the "Restart" tab				
Step 4.7: Configure Sanity Check settings, part 2 In the "Run:" box, locate AlwaysUp_SanityCheck.exe (the files included in the decompressed archive) and add the following arguments as shown in the image and red box below:	Configure Sanity Check Run: ysUp_SanityCheck.exe" \$ALWAYSUP_PID 10 Every: 30 second(s) Wait for: 5 minute(s) before running the first check Also wait whenever the application is restarted Cancel OK				
<mark>"path\to\Always</mark> Where:	Up_SanityCheck.exe" \$ALWAYSUP_PID 120				
 Where: "path\to\AlwaysUp_SanityCheck.exe" The path to the SanityCheck program (.exe file) in your computer \$ALWAYSUP_PID Environment Variable for SanityCheck 120 					
	Configure Sanity Check				
The "Every:" box value should be HALF the amount of seconds as specified after the \$ALWAYSUP_PID argument Example: For "\$ALWAYSUP_PID 120" Use "Every: 60 seconds"	Run: sUp_SanityCheck.exe" \$ALWAYSUP_PID 120 Every: 60 • second(s) • Wait for: • minute(s) before running the first check • Also wait whenever the application is restarted				

Step 4.8: To exit press "OK"	ОК
Step 4.9:	
To finish press "Save >>"	Save >>
	AlwaysUp - licensed to AMI GE International (OEM) File View Application Tools Help
Step 5:	
VisualKB.exe has been added to AlwaysUp	
monitoring	SmartArc "C:\Program Files\AMI GE\Visual KB\VisualKB.exe"
SmartArc/VisualKB should be listed in the	
main AlwaysUp screen.	
	For Help, press F1
Step 5:	
Restart your PC.	
VISUALKES NOULD NOW FUN AS A SERVICE IN	
Should you run into any problems	or if you have any questions, please contact vm2@amige.com